

Standard Instructions for PM's

SOP Code: B3483

Appl/Usage: BERM DRAINING AND INSPECTION

PUMP OR DRAIN ANY ACCUMULATED FLUID FROM THE OIL TANK BERM, THRU AN OIL ABSORBANT MEDIA, TO SEE IF THERE IS ANY LEAKAGE FROM THE TANK. DISPOSE OF THE REMAINING FLUID PROPERLY.

IN THE EVENT THAT THERE IS AN OIL LEAK FROM THE TANK, THE TANK IS TO BE DRAINED, REMOVED AND REPAIRED OR REPLACED. ANY OIL IN THE BURM IS TO BE COLLECTED AND DISPOSED OF PROPERLY.

Copy

Standard Instructions for PM's

SOP Code: B3483

Appl/Usage: BERM DRAINING AND INSPECTION

PUMP OR DRAIN ANY ACCUMULATED FLUID FROM THE OIL TANK BERM, THRU AN OIL ABSORBANT MEDIA, TO SEE IF THERE IS ANY LEAKAGE FROM THE TANK. DISPOSE OF THE REMAINING FLUID PROPERLY.

IN THE EVENT THAT THERE IS AN OIL LEAK FROM THE TANK, THE TANK IS TO BE DRAINED, REMOVED AND REPAIRED OR REPLACED. ANY OIL IN THE BURM IS TO BE COLLECTED AND DISPOSED OF PROPERLY.

Copy

Equipment Information for 3463-06

Equip: 3463-06	Level: 0	Parent: 3463-06	Asset:
Desc: HAZ MATL'S SATTELITE ACCUM. SITE @3200		Dept: 02	Unit: EA
		Bldg: 3200	Risk:
		Area/Room: HAZ ST	Cond:
		Locn: 3200 - 6TH AVE SOUTH	
MFG: ACW	Model#:		
Serial#:	Type: HAZ INSPECTION		

PM Tasks on File for 3463-06

PM Craft: 10-PM	Frequency: Monthly	Task: 001
Work to be Done:	Time (Hrs): 0.50	Last PM'd: 08-08-08
Perform PM Task Using Procedure(s) Listed Below:		
WEEKLY INSPECT SATELLITE AREA PER CHECK LIST DIFICIENCIES & CORRECTIONS NOTED IN LOG BOOK		

PM Craft: 10-PM	Frequency: Monthly	Task: 002
Work to be Done:	Time (Hrs): 0.50	Last PM'd: 08-08-08
Perform PM Task Using Procedure(s) Listed Below:		
CHECK ALL STORM DRAINS TO INSURE THAT FILTER PADS ARE IN PLACE AND IN GOOD SHAPE.		

Equipment Information for 3483-03

Equip: 3483-03

Level: 0

Parent: 3483-03

Asset:

Desc: HAZ MATL'S SATTELITE ACCUM. SITE @ 3405

Dept: 04

Unit: EA

Bldg: 3405

Area/Room: HAZ ST

Risk:

Locn: 3405 - 6TH AVE SOUTH

Cond:

MFG: ACW

Model#:

Serial#:

Type: HAZ INSPECTION

PM Tasks on File for 3483-03

PM Craft: 10-PM

Frequency: Monthly

Task: 001

Work to be Done: Time (Hrs): 0.50

Last PM'd: 08-08-08

Perform PM Task Using Procedure(s) Listed Below:

WEEKLY INSPECT SATELLIT AREA
PER CHECK LIST DEFICIENCIES &
CORRECTIONS NOTED IN LOG BOOK.

PM Craft: 10-PM

Frequency: Monthly

Task: 002

Work to be Done: Time (Hrs): 0.50

Last PM'd: 08-08-08

Perform PM Task Using Procedure(s) Listed Below:

CHECK ALL STORM DRAINS TO
INSURE THAT FILTER PADS ARE IN
PLACE AND IN GOOD SHAPE.

Equipment Information for 3487-06

Equip: 3487-06

Level: 0

Parent: 3487-06

Asset:

Desc: HAZARDOUS MATERIALS STORAGE INSP. @ 628

Dept: 08

Unit: EA

Bldg: 628

Area/Room: HAZ

Risk:

Locn: 628 SOUTH HANFORD

Cond:

MFG: ACW

Model#:

Serial#:

Type: HAZ INSPECTION

PM Tasks on File for 3487-06

PM Craft: 10-PM

Frequency: Monthly

Task: 001

Work to be Done: Time (Hrs): 0.50

Last PM'd: 08-08-08

Perform PM Task Using Procedure(s) Listed Below:

WEEKLY INSPECT STORAGE AREA
PER CHECK LIST DEFICIENCIES &
CORRECTIONS NOTED IN LOG BOOK.

PM Craft: 10-PM

Frequency: Monthly

Task: 002

Work to be Done: Time (Hrs): 0.50

Last PM'd: 08-08-08

Perform PM Task Using Procedure(s) Listed Below:

CHECK ALL STORM DRAINS TO
INSURE THAT FILTER PADS ARE IN
PLACE AND IN GOOD SHAPE.

Equipment Information for 3491-06

Equip: 3491-06	Level: 0	Parent: 3491-06	Asset:
Desc: HAZ MATL'S SATTELITE ACCUM. SITE @ 3223		Dept: 01	Unit: EA
		Bldg: 3223	Risk:
		Area/Room: HAZ ST	Cond:
		Locn: 3223 - 6TH AVE SOUTH	
MFG: ACW	Model#:		
Serial#:	Type: HAZ INSPECTION		

PM Tasks on File for 3491-06

PM Craft: 10-PM	Frequency: Monthly	Task: 001
Work to be Done:	Time (Hrs): 0.50	Last PM'd: 08-08-08
Perform PM Task Using Procedure(s) Listed Below:		
WEEKLY INSPECT SATELLITE AREA		
PER CHECK LIST DEFICIENCIES &		
CORRECTIONS NOTED IN LOG BOOK.		

PM Craft: 10-PM	Frequency: Monthly	Task: 002
Work to be Done:	Time (Hrs): 0.50	Last PM'd: 08-08-08
Perform PM Task Using Procedure(s) Listed Below:		
CHECK ALL STORM DRAINS TO		
INSURE THAT FILTER PADS ARE IN		
PLACE AND IN GOOD SHAPE		

Standard Instructions for PM's

SOP Code: B3483

Appl/Usage: BERM DRAINING AND INSPECTION

PUMP OR DRAIN ANY ACCUMULATED FLUID FROM THE OIL TANK BERM, THRU AN OIL ABSORBANT MEDIA, TO SEE IF THERE IS ANY LEAKAGE FROM THE TANK. DISPOSE OF THE REMAINING FLUID PROPERLY.

IN THE EVENT THAT THERE IS AN OIL LEAK FROM THE TANK, THE TANK IS TO BE DRAINED, REMOVED AND REPAIRED OR REPLACED. ANY OIL IN THE BURM IS TO BE COLLECTED AND DISPOSED OF PROPERLY.

Standard Instructions for PM's

SOP Code: B3483

Appl/Usage: BERM DRAINING AND INSPECTION

PUMP OR DRAIN ANY ACCUMULATED FLUID FROM THE OIL TANK BERM, THRU AN OIL ABSORBANT MEDIA, TO SEE IF THERE IS ANY LEAKAGE FROM THE TANK. DISPOSE OF THE REMAINING FLUID PROPERLY.

IN THE EVENT THAT THERE IS AN OIL LEAK FROM THE TANK, THE TANK IS TO BE DRAINED, REMOVED AND REPAIRED OR REPLACED. ANY OIL IN THE BURM IS TO BE COLLECTED AND DISPOSED OF PROPERLY.